



X-ACT CONTOUR

FLOOR LINERS

CARE AND USE INSTRUCTIONS - PN: 53498

Thank you for selecting X-act Contour™ Front Floor Liners from Husky Liners Inc. Your new front floor liners are custom molded to fit your specific vehicle's floor board. The liners are made to take the place of your factory floor mats. ***For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners. However, do not remove the factory-installed carpeting.***

Your liners are made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liners is with a damp cloth or sponge and soap and water. Windex®, 409® and ArmorAll® type cleaners work as well.



LEFT OR DRIVER



RIGHT OR PASSENGER

TO INSTALL YOUR NEW LINERS, POSITION THEM IN THE FLOOR PAN AS SHOWN ABOVE. THE LINERS ATTACH TO THE FACTORY FLOOR MAT RETAINING POSTS. JUST ALIGN THE LINERS OVER THE POSTS AND PRESS DOWNWARD TO SNAP THEM OVER THE POSTS. YOUR LINER SET INCLUDES A RETAINER THAT CAN BE ADDED TO THE PASSENGER SIDE FLOOR. PLEASE SEE THE INSTRUCTIONS ON THE BACK OF THIS PAGE THAT DETAIL ADDING THIS RETAINER.

HUSKY FLOOR LINER RETAINING CLIP INSTALLATION INSTRUCTIONS

YOUR LINER SET INCLUDES OUR NEW FLOOR LINER RETAINING CLIP. THIS RETAINING CLIP GIVES THE EXTRA SECURITY WHILE KEEPING SPILLS AND DEBRIS TRAPPED INSIDE THE LINERS. TO INSTALL THE HUSKY® LINER RETAINING CLIPS, SIMPLY FOLLOW THE INSTRUCTIONS BELOW:

- 1) Pre fit your new Xact Contour floor liner in your vehicle (Image 1).
- 2) Insert the screw-in carpet retention screw into the bottom of the Xact Contour liner (Image 2).
- 3) Press down on the liner to pre-mark the carpet screw into the carpet (Image 3).
- 4) Screw the carpet screw into the carpet with a flat blade screwdriver (Image 4).
- 5) Press the Xact Contour liner over the top of the carpet screw post (Image 3).



IF YOU HAVE ANY QUESTIONS REGARDING THE INSTALLATION OF YOUR HUSKY® LINER RETAINING CLIPS, JUST GIVE US A CALL MONDAY THROUGH FRIDAY FROM 8:00 AM - 5:00 PM CENTRAL TIME AT 800-344-8759 OR E-MAIL US AT: contactus@huskyliners.com.



X-ACT CONTOUR

FLOOR LINERS

CARE AND USE INSTRUCTIONS – PN: 53468

Thank you for selecting an X-act Contour™ 2nd Seat Floor Liner from Husky Liners Inc. Your new floor liner is custom molded to fit your specific vehicle's floor board. The liner is made to take the place of your factory floor mats. ***For correct fit, it is necessary to remove the factory floor mats before installing your new floor liner. However, do not remove the factory-installed carpeting.***

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge and soap and water. Windex®, 409® and ArmorAll® type cleaners work as well.



TO EASE INSTALLATION OF YOUR SECOND SEAT FLOOR LINER, FIRST FOLD UP THE REAR SEAT BOTTOMS AND MOVE THE FRONT SEATS TO THEIR MOST FORWARD POSITION. ONCE YOUR LINER IS INSTALLED, REPOSITION THE FRONT SEATS AS DESIRED.