

S6168	C	06	/19	9





Figure 1



Figure 2



Figure 3



Figure 4

Removal of Stock System:

1. Apply a penetrating lubricant liberally to all exhaust fasteners, hangers and rubber insulators.

2. Loosen the nut on the clamp on the factory tailpipe. **Refer to Figure 1.**

3. Remove the tail pipe from the OEM extension pipe then from the OEM rubber hanger. Remove the stock tail pipe from the vehicle. Completely remove the OEM rubber tail pipe hanger as it will not be reused.

4. Temporarily lower the spare tire.

Installation of MBRP Performance Exhaust:

1. Remove the 2 rear bolts retaining the spare tire heat shield. **Refer to Figure 2.**

2. Install the **Hanger Assemblies**, centered in the frame holes, using the provided hardware, keeping the 7/16" Fender Washers next to the frame. Do not completely tighten until all of the pipes are in place. This allows for final adjustment of the Tail Pipes. Refer to Figures 2 (passenger side) and 3 (driver side).

3. Slide a **4**" **Clamp** onto the outlet end of the factory extension pipe. Install the **Y Pipe** as shown, taking care to align the tab on the extension pipe with the slot in the **Y Pipe**. **Refer to Figure 4.**





4. Slide one **4"** Clamp and the Driver Side Tail Pipe onto the left hand outlet of the Y Pipe keeping the brake flex hoses and ABS wiring in front of the pipe.

Refer to Figure 5.

Figure 5



5. Install the Driver Side Tail Pipe hanger into the Hanger Assembly. Refer to Figure 6.





Figure 7



Figure 8

6. Install the **Passenger Side Tail Pipe** using a **4**" **Clamp** onto the right hand outlet of the **Y Pipe**. **Refer to Figure 7.**

7. Install the **Passenger Side Tail Pipe** hanger into the **Hanger Assembly**. **Refer to Figure 8.**

8. Align the exhaust and tighten the **Hanger Assembly** hardware on both sides.





Figure 9



Figure 10

9. Reinstall the spare tire heat shield and raise the spare tire keeping it as far to the right rear of the vehicle as possible. **Refer to Figure 9.**

10. Align the exhaust as required. Starting at the front of the exhaust, tighten all clamps, hangers and connections.

11. Install the **Exhaust Tips**. Single rear wheel owners may wish to trim the length of the tail pipes to suit. The Tail Pipes are purposely left long for dual rear wheel applications.

Refer to Figure 10.

12. Check along the whole length of the exhaust system to ensure that there is adequate clearance around the spare tire, fuel and brake lines or any wiring. If any interference is detected relocate or adjust. Pay particular attention to the brake flex lines and ABS wiring on the driver's side. Most often these can be kept clear of the exhaust by loosely tying them back to the emergency brake cable. Different configurations may require different methods. It is the installer's responsibility to ensure there is enough clearance to prevent damage.



Congratulations! You are ready to begin experiencing the improved power, sound and driving experience of your **MBRP** performance exhaust system. We know you will enjoy your purchase.